

**580N EP**  
**Tier 4B (final)**  
Tractor Loader Backhoe  
*PIN NHC740227 and above*

**SERVICE MANUAL**

**Part number 48194542**  
1<sup>st</sup> edition English  
November 2017





## **SERVICE MANUAL**

**580N EP Four-Wheel Drive (4WD) Tier 4B (final) [NHC740227 - ]**  
**580N EP Two-Wheel Drive (2WD) Tier 4B (final) [NHC740227 - ]**

## Link Product / Engine

---

<b>Product</b>	<b>Market Product</b>	<b>Engine</b>
580N EP Two-Wheel Drive (2WD) Tier 4B (final) [NHC740227 - ]	North America	F5HFL463D*F005
580N EP Four-Wheel Drive (4WD) Tier 4B (final) [NHC740227 - ]	North America	F5HFL463D*F005

# Contents

---

## INTRODUCTION

<b>Engine</b> .....	<b>10</b>
[10.001] Engine and crankcase .....	10.1
[10.103] Crankshaft and flywheel.....	10.2
[10.202] Air cleaners and lines .....	10.3
[10.206] Fuel filters .....	10.4
[10.216] Fuel tanks .....	10.5
[10.218] Fuel injection system.....	10.6
[10.304] Engine lubrication system.....	10.7
[10.400] Engine cooling system .....	10.8
[10.414] Fan and drive .....	10.9
[10.501] Exhaust Gas Recirculation (EGR) exhaust treatment.....	10.10
<b>Transmission</b> .....	<b>21</b>
[21.112] Power shuttle transmission.....	21.1
[21.113] Powershift transmission .....	21.2
[21.134] Power shuttle transmission external controls .....	21.3
[21.135] Powershift transmission external controls.....	21.4
[21.154] Power shuttle transmission internal components .....	21.5
[21.155] Powershift transmission internal components.....	21.6
<b>Front axle system</b> .....	<b>25</b>
[25.100] Powered front axle .....	25.1
[25.102] Front bevel gear set and differential .....	25.2
[25.108] Final drive hub, steering knuckles, and shafts .....	25.3
[25.400] Non-powered front axle .....	25.4
<b>Rear axle system</b> .....	<b>27</b>
[27.100] Powered rear axle.....	27.1

[27.106] Rear bevel gear set and differential .....	27.2
[27.120] Planetary and final drives .....	27.3
<b>Brakes and controls .....</b>	<b>33</b>
[33.110] Parking brake or parking lock .....	33.1
[33.202] Hydraulic service brakes .....	33.2
<b>Hydraulic systems.....</b>	<b>35</b>
[35.000] Hydraulic systems.....	35.1
[35.102] Pump control valves.....	35.2
[35.104] Fixed displacement pump.....	35.3
[35.204] Remote control valves .....	35.4
[35.300] Reservoir, cooler, and filters.....	35.5
[35.350] Safety and main relief valves .....	35.6
[35.357] Pilot system .....	35.7
[35.359] Main control valve .....	35.8
[35.525] Auxiliary hydraulic valves and lines .....	35.9
[35.701] Front loader arm hydraulic system .....	35.10
[35.703] Stabilizer hydraulic system .....	35.11
[35.723] Front loader bucket hydraulic system .....	35.12
[35.726] Excavator and backhoe hydraulic controls.....	35.13
[35.736] Boom hydraulic system .....	35.14
[35.737] Dipper hydraulic system.....	35.15
[35.738] Excavator and backhoe bucket hydraulic system.....	35.16
[35.739] Swing arm hydraulic system .....	35.17
[35.740] Telescopic arm hydraulic system.....	35.18
<b>Frames and ballasting .....</b>	<b>39</b>
[39.100] Frame .....	39.1
[39.129] Stabilizers .....	39.2
<b>Steering.....</b>	<b>41</b>

[41.101] Steering control .....	41.1
[41.200] Hydraulic control components.....	41.2
[41.216] Cylinders .....	41.3
<b>Wheels .....</b>	<b>44</b>
[44.511] Front wheels.....	44.1
[44.520] Rear wheels .....	44.2
<b>Cab climate control .....</b>	<b>50</b>
[50.100] Heating .....	50.1
[50.200] Air conditioning.....	50.2
<b>Electrical systems .....</b>	<b>55</b>
[55.100] Harnesses and connectors.....	55.1
[55.201] Engine starting system .....	55.2
[55.301] Alternator.....	55.3
[55.302] Battery.....	55.4
[55.404] External lighting .....	55.5
[55.408] Warning indicators, alarms, and instruments .....	55.6
[55.510] Cab or platform harnesses and connectors.....	55.7
[55.640] Electronic modules .....	55.8
[55.991] Telematics .....	55.9
[55.DTC] FAULT CODES.....	55.10
<b>Front loader and bucket.....</b>	<b>82</b>
[82.100] Arm.....	82.1
[82.300] Bucket.....	82.2
<b>Booms, dippers, and buckets .....</b>	<b>84</b>
[84.100] Bucket.....	84.1
[84.114] Boom pivoting support .....	84.2
[84.910] Boom .....	84.3
[84.912] Dipper arm .....	84.4

Platform, cab, bodywork, and decals .....	90
[90.100] Engine hood and panels .....	90.1
[90.114] Operator protections .....	90.2
[90.124] Pneumatically-adjusted operator seat.....	90.3
[90.150] Cab .....	90.4
[90.151] Cab interior.....	90.5
[90.154] Cab doors and hatches .....	90.6
[90.156] Cab windshield and windows .....	90.7



## **INTRODUCTION**



# Contents

---

## INTRODUCTION

Foreword - Important notice regarding equipment servicing .....	4
Safety rules .....	5
Safety rules - Personal safety .....	6
Safety rules - Ductile iron .....	7
Safety rules - Ecology and the environment .....	8
Basic instructions - Shop and assembly .....	9
Basic instructions - Fuse and relay locations .....	11
Basic instructions - Fuse, relay, and diode icon definitions .....	16
Basic instructions - Releasing hydraulic pressure on machines with pilot backhoe controls .	23
Basic instructions - Releasing hydraulic pressure on machines with mechanical backhoe controls .....	25
Basic instructions - Diagnostic service tool port .....	26
Basic instructions - Hydraulic diagnostic test ports .....	27
Basic instructions - Welding on the machine .....	28
Basic instructions - Heater coolant shutoff valve .....	30
Engine cooling system - Basic instructions .....	31
Basic instructions - Support strut for loader lift arm .....	33
Basic instructions - Hood .....	35
Torque - Minimum tightening torques for normal assembly .....	36
Torque - Standard torque data for hydraulics .....	41
Basic instructions - Snap-to-Connect (STC®) hydraulic connectors .....	57
Abbreviation Measurements .....	62
Capacities and fluids - 580N EP (factory fill) .....	64
Consumables .....	66
General specification - Engine oils .....	68
General specification - Severe Cold Weather Package (SCWP) .....	69
Hydraulic contamination .....	70
General specification - Engine .....	71
General specification - Powertrain .....	72
General specification - Hydraulics .....	74
General specification - Travel speeds .....	75
General specification - Machine overall dimensions .....	76
General specification - Loader lift capacities .....	79
General specification - Backhoe/Extendahoe specifications and lifting capacities .....	80
General specification - Noise levels .....	90
Product identification - Machine orientation .....	91

Part identification .....	92
Product identification - Product Identification Number (PIN) .....	94

---

## **Foreword - Important notice regarding equipment servicing**

All repair and maintenance work listed in this manual must be carried out only by qualified dealership personnel, strictly complying with the instructions given, and using, whenever possible, the special tools.

Anyone who performs repair and maintenance operations without complying with the procedures provided herein shall be responsible for any subsequent damages.

The manufacturer and all the organizations of its distribution chain, including - without limitation - national, regional, or local dealers, reject any responsibility for damages caused by parts and/or components not approved by the manufacturer, including those used for the servicing or repair of the product manufactured or marketed by the manufacturer. In any case, no warranty is given or attributed on the product manufactured or marketed by the manufacturer in case of damages caused by parts and/or components not approved by the manufacturer.

The manufacturer reserves the right to make improvements in design and changes in specifications at any time without notice and without incurring any obligation to install them on units previously sold. Specifications, descriptions, and illustrative material herein are as accurate as known at time of publication but are subject to change without notice.

In case of questions, refer to your CASE CONSTRUCTION Sales and Service Networks.

## Safety rules


### Personal safety





This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible death or injury.

Throughout this manual you will find the signal words DANGER, WARNING, and CAUTION followed by special instructions. These precautions are intended for the personal safety of you and those working with you.

Read and understand all the safety messages in this manual before you operate or service the machine.

 DANGER indicates a hazardous situation that, if not avoided, will result in death or serious injury.

 WARNING indicates a hazardous situation that, if not avoided, could result in death or serious injury.

 CAUTION indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

**FAILURE TO FOLLOW DANGER, WARNING, AND CAUTION MESSAGES COULD RESULT IN DEATH OR SERIOUS INJURY.**

### Machine safety

**NOTICE:** Notice indicates a situation that, if not avoided, could result in machine or property damage.

Throughout this manual you will find the signal word Notice followed by special instructions to prevent machine or property damage. The word Notice is used to address practices not related to personal safety.

### Information

**NOTE:** Note indicates additional information that clarifies steps, procedures, or other information in this manual.

Throughout this manual you will find the word Note followed by additional information about a step, procedure, or other information in the manual. The word Note is not intended to address personal safety or property damage.

## **Safety rules - Personal safety**

Unless otherwise instructed, always perform these steps before you service the machine:

1. Park the machine on a flat, level surface.
2. Place the backhoe in the transport position with the swing lock pin installed for transport.
3. Place the loader bucket on the ground, with the bottom of the loader bucket parallel to the surface.
4. Place the direction control lever and the transmission in neutral.
5. If you need to open the hood to perform service, raise the loader arms and install the support strut.
6. Shut down the engine.
7. Place a 'Do Not Operate' tag on the key switch so that it is visible to other workers or remove the key.

---

## Safety rules - Ductile iron



### **▲ DANGER**

**Altering cast ductile iron can cause it to weaken or break.**

**Before you weld, cut, or drill holes on any part of this machine, make sure that the part is not cast ductile iron.**

**Failure to comply will result in death or serious injury.**

D0148A

Altering cast ductile iron can cause it to weaken or break. Unauthorized modifications to cast ductile iron parts can cause death or serious injury. Do not weld, cut, drill, repair, or attach items to cast ductile iron parts on this machine.

Before you weld, cut, or drill holes on any part of this machine, make sure the part is not cast ductile iron. See your dealer if you do not know if a part is cast ductile iron.

The following items are examples of cast ductile iron parts. There may also be other parts made of cast ductile iron that are not on the list below.

- two-wheel drive steering link
- dump links
- front axle
- stabilizers
- extend-a-hoe
- swing tower
- bucket linkage
- Air-Conditioning (A/C) compressor mounting bracket

Do not make any unauthorized modifications. Consult an authorized dealer before making any changes, additions, or modifications to this machine.

---

## Safety rules - Ecology and the environment

Soil, air, and water quality is important for all industries and life in general. When legislation does not yet rule the treatment of some of the substances that advanced technology requires, sound judgment should govern the use and disposal of products of a chemical and petrochemical nature.

Familiarize yourself with the relative legislation applicable to your country, and make sure that you understand this legislation. Where no legislation exists, obtain information from suppliers of oils, filters, batteries, fuels, anti-freeze, cleaning agents, etc., with regard to the effect of these substances on man and nature and how to safely store, use, and dispose of these substances.

### Helpful hints

- Avoid the use of cans or other inappropriate pressurized fuel delivery systems to fill tanks. Such delivery systems may cause considerable spillage.
- In general, avoid skin contact with all fuels, oils, acids, solvents, etc. Most of these products contain substances that may be harmful to your health.
- Modern oils contain additives. Do not burn contaminated fuels and or waste oils in ordinary heating systems.
- Avoid spillage when you drain fluids such as used engine coolant mixtures, engine oil, hydraulic fluid, brake fluid, etc. Do not mix drained brake fluids or fuels with lubricants. Store all drained fluids safely until you can dispose of the fluids in a proper way that complies with all local legislation and available resources.
- Do not allow coolant mixtures to get into the soil. Collect and dispose of coolant mixtures properly.
- The air-conditioning system contains gases that should not be released into the atmosphere. Consult an air-conditioning specialist or use a special extractor to recharge the system properly.
- Repair any leaks or defects in the engine cooling system or hydraulic system immediately.
- Do not increase the pressure in a pressurized circuit as this may lead to a component failure.
- Protect hoses during welding. Penetrating weld splatter may burn a hole or weaken hoses, allowing the loss of oils, coolant, etc.

### Battery recycling

Batteries and electric accumulators contain several substances that can have a harmful effect on the environment if the batteries are not properly recycled after use. Improper disposal of batteries can contaminate the soil, groundwater, and waterways. CASE CONSTRUCTION strongly recommends that you return all used batteries to a CASE CONSTRUCTION dealer, who will dispose of the used batteries or recycle the used batteries properly. In some countries, this is a legal requirement.



### Mandatory battery recycling

**NOTE:** The following requirements are mandatory in Brazil.

Batteries are made of lead plates and a sulfuric acid solution. Because batteries contain heavy metals such as lead, CONAMA Resolution 401/2008 requires you to return all used batteries to the battery dealer when you replace any batteries. Do not dispose of batteries in your household garbage.

Points of sale are obliged to:

- Accept the return of your used batteries
- Store the returned batteries in a suitable location
- Send the returned batteries to the battery manufacturer for recycling

---

## Basic instructions - Shop and assembly

### Shimming

For each adjustment operation, select adjusting shims and measure the adjusting shims individually using a micrometer, then add up the recorded values. Do not rely on measuring the entire shimming set, which may be incorrect, or the rated value shown on each shim.

### Rotating shaft seals

For correct rotating shaft seal installation, proceed as follows:

1. Before assembly, allow the seal to soak in the oil it will be sealing for at least thirty minutes.
2. Thoroughly clean the shaft and check that the working surface on the shaft is not damaged.
3. Position the sealing lip facing the fluid.

**NOTE:** *With hydrodynamic lips, take into consideration the shaft rotation direction and position the grooves so that they will move the fluid towards the inner side of the seal.*

4. Coat the sealing lip with a thin layer of lubricant (use oil rather than grease). Fill the gap between the sealing lip and the dust lip on double lip seals with grease.
5. Insert the seal in its seat and press down using a flat punch or seal installation tool. Do not tap the seal with a hammer or mallet.
6. While you insert the seal, check that the seal is perpendicular to the seat. When the seal settles, make sure that the seal makes contact with the thrust element, if required.
7. To prevent damage to the seal lip on the shaft, position a protective guard during installation operations.

### O-ring seals

Lubricate the O-ring seals before you insert them in the seats. This will prevent the O-ring seals from overturning and twisting, which would jeopardize sealing efficiency.

### Sealing compounds

Apply a sealing compound on the mating surfaces when specified by the procedure. Before you apply the sealing compound, prepare the surfaces as directed by the product container.

### Spare parts

Only use CNH Original Parts or CASE CONSTRUCTION Original Parts.

Only genuine spare parts guarantee the same quality, duration, and safety as original parts, as they are the same parts that are assembled during standard production. Only CNH Original Parts or CASE CONSTRUCTION Original Parts can offer this guarantee.

When ordering spare parts, always provide the following information:

- Machine model (commercial name) and Product Identification Number (PIN)
- Part number of the ordered part, which can be found in the parts catalog



---

## Protecting the electronic and/or electrical systems during charging and welding

To avoid damage to the electronic and/or electrical systems, always observe the following practices:

1. Never make or break any of the charging circuit connections when the engine is running, including the battery connections.
2. Never short any of the charging components to ground.
3. Always disconnect the ground cable from the battery before arc welding on the machine or on any machine attachment.
  - Position the welder ground clamp as close to the welding area as possible.
  - If you weld in close proximity to a computer module, then you should remove the module from the machine.
  - Never allow welding cables to lie on, near, or across any electrical wiring or electronic component while you weld.
4. Always disconnect the negative cable from the battery when charging the battery in the machine with a battery charger.

**NOTICE:** *If you must weld on the unit, you must disconnect the battery ground cable from the machine battery. The electronic monitoring system and charging system will be damaged if this is not done.*

5. Remove the battery ground cable. Reconnect the cable when you complete welding.

### WARNING

**Battery acid causes burns. Batteries contain sulfuric acid.**

**Avoid contact with skin, eyes or clothing. Antidote (external): Flush with water. Antidote (eyes): flush with water for 15 minutes and seek medical attention immediately. Antidote (internal): Drink large quantities of water or milk. Do not induce vomiting. Seek medical attention immediately. Failure to comply could result in death or serious injury.**

W0111A

## Special tools

The special tools that CASE CONSTRUCTION suggests and illustrate in this manual have been specifically researched and designed for use with CASE CONSTRUCTION machines. The special tools are essential for reliable repair operations. The special tools are accurately built and rigorously tested to offer efficient and long-lasting operation.

By using these tools, repair personnel will benefit from:


- Operating in optimal technical conditions
- Obtaining the best results
- Saving time and effort
- Working in safe conditions

## Basic instructions - Fuse and relay locations

The machine is equipped with five fuse box locations. Two locations in the front console, a side console box and two external locations (Glow-plug Control Unit and Telematics System).


### Front console box

1. Turn the thumb screw (1) to loosen the panel cover (2) for the fuse box. Remove the panel cover.




RCPH10TLB320AAF 1

2. Remove the fuse box cover.




RCPH10TLB307AAF 2



RCPH10TLB303AAF 3


3. Refer to the decal on the interior side of the panel cover for fuse, relay, and/or diode functions.



RCPH10TLB310AAF 4


### Front console ECU fuse and relay

1. Remove the cover from the steering column shroud.



RAPH11TLB012BAD 5


Fuse or relay reference	Designation
(1)	ECU B+ relay
(2)	ECU B+ 20 A fuse
(3)	ECU B+ 7.5 A fuse
(4)	LAMBDA SENSOR B+ 7.5 A fuse



RAPH12TLB0016BA 6


## Side console box

1. Turn the thumb screws (1) to loosen the panel cover (2) for the fuse box. Remove the panel cover.



RCPH10TLB437AAF 7

2. Remove the fuse box covers (1) as needed.



RAIL16TLB0527BA 8

3. Refer to the decal on the interior side of the panel cover for fuse, relay, and/or diode functions.




RCPH10TLB319AAF 9

---

### Glow-plug Control Unit (GCU) fuse


1. Raise the loader arm and engage the safety support.
2. Lift the engine hood.
3. Locate the **60 A** fuse box for the GCU on the right hand side of the engine attached to the cab frame.




RAPH12TLB0017BA 10

### Telematics system fuse

1. Raise the loader arm and engage the safety support.
2. Lift the engine hood.
3. On the right-hand side of the engine locate the wire harness with the in-line **5 A** fuse. The location of the fuse will depend on the machine configuration:
  - A. Machines equipped with the Battery Power Junction Stud **(1)** .
  - B. Machines equipped with a Master Disconnect Switch **(2)**.




RAIL13TLB0207BA 11







RAIL13TLB0206BA 12

# Basic instructions - Fuse, relay, and diode icon definitions
















## Right-hand side console panel



## Fuse icon definitions










Symbol	Function
	ECU B+
	Instrument cluster key ON
	TRAX B+
	Instrument cluster B+

INTRODUCTION














Symbol	Function
	Rear lights
	Rear wipers/washers
	Transmission differential lock
	Tail lights
	Pilot controls
	Auxiliary plugs
	4WD, Auto Ride Control
	Dome light
	Radio B+
	Horn
	Blower motor
	A/C
	Key switch
	Air seat
	2WD, Ride Control



INTRODUCTION









Symbol	Function
	Quick coupler, EH Clam, Radio Key ON
	SAHR brake
	Comfort Steer
	Side lights
	Customer B+
	Customer key ON
	<b>Power Lift™</b>
	Starter
	Telematics <b>NOTE:</b> The Telematics system has an additional external fuse location. See "Basic instructions - Fuse and relay locations" <b>Basic instructions - Fuse and relay locations</b> ().

Relay icon definitions

Symbol	Function
	Power relay #1
	Power relay #2
	Power Lift™ relay
	SAHR park brake relay
	SAHR park brake transmission cutout relay
	Forward relay (Power Shuttle only)
	A/C relay
	Comfort Steer relay (Power Shuttle only)
	Reverse relay (Power Shuttle only)
	Neutral relay
	Starter interlock relay
	Auto Ride Control relay
	Rear light relay

INTRODUCTION

Diode icon definitions

Symbol	Function
	Quick coupler diode #1
	Quick coupler diode #2
	Quick coupler diode #3
	Quick coupler diode #4
	Quick coupler diode #5
	Reverse signal diode (Power Shuttle only)
	Forward signal diode (Power Shuttle only)
	Torque control diode

Left-hand side steering column console panel

Power Shuttle					Powershift				
84386692A 3					84386693 4				




Fuse icon definitions

Symbol	Function
	Head lights
	Front work lights
	Turn signal, Hazards
	Front wiper/washer
	High beam
	Beacon



Relay icon definitions

Symbol	Function
	Comfort steer relay and Power relay #1 (Power Shuttle only)
	Comfort steer relay and Power relay #2 (Power Shuttle only)
	Power relay #3
	Power relay #4

## INTRODUCTION

Symbol	Function
	Transmission De-clutch relay (Powershift only)
	Transmission lock relay (Powershift only)
	Start relay

### Diode icon definitions


Symbol	Function
	Reverse Signal Diode (Power Shuttle only)
	Forward Signal Diode (Power Shuttle only)

## Basic instructions - Releasing hydraulic pressure on machines with pilot backhoe controls

1. Park the machine on firm level ground.
2. Put all transmission controls in the Neutral position.
3. Engage the parking brake.
4. Lower the bucket to the ground but do not apply down pressure; or raise the loader arm and engage the loader arm safety support.
5. Rotate the operator seat into the backhoe operation position.
6. Place the backhoe in the stowed position with swing lock pin in the lock position. If applicable, insert the Extendahoe lock pin. You may choose to rest the backhoe attachment on the ground.
7. Shut off the engine.
8. Turn the key switch to the ON position but DO NOT start the engine.
9. Press the emblem end of the backhoe and stabilizer control switch to activate all backhoe controls.

**NOTE:** When turning the backhoe and stabilizer control switch to the ON position, wait approximately half a second before activating the stabilizers, **Extendahoe®** (if equipped) or bi-directional auxiliary hydraulics (if equipped). If an operator attempts to operate the functions before the delay passes, the functions will not operate. Cycle the power switch and wait for the delay to pass.

10. If equipped with combo auxiliaries, enable the bi-directional switch on the right-hand side panel.
11. Cycle the bi-directional proportional control buttons on the left-hand pilot control joystick.
12. Move each pilot backhoe control joystick in one complete circle, stopping in the neutral (center) position.
13. Deactivate the backhoe and stabilizer control switch.
14. Rotate the operator seat into the driving position.



LEEN12T0487AA 1

**Thanks for your reading.**

**Please click here to download complete manual instantly.**

**And can also choose other manuals.**

**Feel free --->write to me with any questions.**

**Our service email:**

**manuals007@hotmail.com**