WX145 WX165 WX185

HYDRAULIC EXCAVATOR

Service manual

Print No. 9-91221 English



THIS ALERT SYMBOL SIGNALS IMPORTANT MESSAGES INVOLVING YOUR SAFETY.

Read and heed carefully the safety instructions listed and follow the precautions recommended to avoid potential risks and to safeguard your health and your safety.

You will find this symbol in the text of this Manual referred to the following key words:

WARNING - Cautions directed to avoid improper repair interventions involving potential consequences for the safety of the personnel performing the repairs.

DANGER - These warnings qualify specifically potential dangers for the safety of the operator or other persons directly or indirectly involved.

IMPORTANT NOTICE

All maintenance and repair interventions explained in this Manual **must be performed exclusively by the Service Organisation of the Manufacturer**, observing strictly the instructions explained using, whenever necessary, the recommended specific tools.

Whoever performs the operations reported without following exactly the precautions is responsible on his own, for the damages that may result.

Neither the Factory nor any Organisations in its Distribution Network, including but not limited to national, regional or local distributors, are responsible for any liability arising from any damage resulting from defects caused by parts and/or components not approved by the Factory for use in maintaining and/or repairing products manufactured or merchandised by the Factory.

In any case, no warranty of any kind is made or shall be imposed with respect to products manufactured or merchandised by the Factory, when failures are caused by the use of parts and/or components not approved by the Factory.

AVOID ACCIDENTS

Most accidents, whether they occur in industry, on the farm, at home or on the road, are caused by the failure of some individuals to follow simple and fundamental safety rules and precautions. For this reason MOST ACCIDENTS CAN BE PREVENTED by recognising the real cause and doing something about it before the accident occurs.

Regardless of the care used in the design and construction of any type of equipment, there are many conditions that cannot be completely safeguarded against without interfering in the reasonable accessibility and efficient operation.

A careful operator is the best insurance against an accident. The complete observance of one simple rule would prevent many serious accidents.

The rule is simple: never attempt to clean, lubricate or maintain a machine while it is in motion.



Prior to engaging in any maintenance, adjustment or repair operation on machines having hydraulically, mechanically, and/or cable controlled equipment (such as shovels, loaders, dozers, excavators etc.) be certain the equipment is lowered to the ground.

If it is necessary to have the equipment partially or fully raised to gain access to certain items, be sure the equipment is suitably supported by means other than the devices used for controlling the equipment.

SUMMARY

SAFETY INSTRUCTIONS	SECTION 1
TECHNICAL DATA AND SPECIAL TOOLS	SECTION 2
MACHINE STRUCTURE	SECTION 3
ELECTRICAL SYSTEM	SECTION 4
ELECTRONICS	SECTION 5
HYDRAULICS	SECTION 6
TROUBLESHOOTING AND REPAIR	SECTION 7
REPAIR INSTRUCTIONS	SECTION 8

40000701.00-en





Service manual

Section 1 Safety Instructions

(€

WX145 - WX165 - WX185

REPRODUCTION OF THESE OPERATING INSTRUCTIONS IN WHOLE OR IN PART IS STRICTLY PROHIBITED EXCEPT WITH THE WRITTEN CONSENT OF THE PUBLISHER

The data contained in this handbook were valid at the time of publication. As we constantly endeavour to improve our products and to provide additional options, modifications or changes made in this context may have an impact on the procedures described in this handbook. Please contact your local dealer if you find any discrepancies.

This page left blank intentionally

Table of contents

PREFACE	6
To the reader	6
Handling	
Repair	6
Further information material	6
Warnings and symbols	7
Risks resulting from failure to observe the safety instructi	ons7
SAFETY INSTRUCTIONS	8
Personal safety instructions	8
Observe the safety instructions	
Protection from noise	8
Preparing for emergencies	8
Wearing protective clothing	
Safety instructions before starting work	10
Checking the machine	
Keeping the working area clean	
Using grab handles and steps	
Adjusting the operator's seat	11
Applying the safety belt	12
Working from the operator's seat only	12
Never take passengers on the machine	12
Safety instructions for machine operation	13
Before setting off	
Note the position of the working equipment	13
Taking care during operation	13
Taking care when trenching	14
Distance from overhead power lines	14
Accident Prevention when reversing and slewing	
Rules for driving on the road	
Recovering and towing the machine	
Travelling uphill and downhill	
Preventing the machine from overturning	
Inspecting the deployment location	
Parking the machine safely	
Preventing accidents when the machine is moving	
Confirming the direction of machine travel	
Avoid caving out high banks	
Protection from rockfall and landslides	
Caving prevention	
Never move the bucket above persons	21

Safety instructions, maintenance/servicing	
Safety during transport	
Safety during servicing operations	
Warning instructions for servicing work	
Correct machine support	
Working at greater heights	
Keeping clear of moving parts	25
Prestressed units	
Never remove lead seals	
Dismantling components	
After repair work	
Correct waste disposal	
Welding operations	
Starting the engine with starter batteries	
Prevention of acid-induced burns	
Prevention of scalding	
Safe handling of fluids	30
Fire prevention	
Evacuation in case of fire	
Risks from exhaust gases	
Risks from fluids in pressure systems	
Preventing heat build-up close to pressure systems	
Preventing heat build-up in lines carrying combustible fluids	
Removing paint before weldingRisks from breaking-away components	
Use appropriate tools	
Warning and instruction signs (mono-boom)	38
Warning and instruction signs (boom adjusting equipment)	42
Warning and instruction signs (mono-boom)	46
3 • • • • • • • • • • • • • • • • • • •	
Warning and instruction signs (boom adjusting equipment)	50
Organizational measures	54
Safety instructions governing specific operational phases	55
Standard operation	55
Warning of special dangers	
Electric energy	57
Gas, dust, steam and smoke	
Hydraulic and pneumatic equipment	
Noise	58
Oil, grease and other chemical substances	58
Transporting and towing: recommissioning	58

Thanks for your reading.

Please click here to download complete manual instantly.

And can also choose other manuals.

Feel free --->write to me with any questions.

Our service email:

manuals007@hotmail.com