

R190 R190 (EU) R190 X-Series

GEHL®

Form No.
50950170

Revision A
03/14

Skid-Steer Loader



PARTS MANUAL

Introduction

For your safety and continued proper operation, use only genuine GEHL® service parts. When ordering service parts, specify the correct part number, full description, quantity required, the unit model number and serial number.

The model and serial number decal for this unit is located on the left chassis upright. “Right” and “Left” are determined from a position sitting on the seat and facing forward.

Manitou Americas reserves the right to make changes or improvements in the design or construction of any part of the unit without incurring the obligation to install such changes on any previously delivered units.

NOTE: Purchase equivalent, quality tires for your loader. Contact your dealer for replacement tire information.

NOTE: Replacement batteries are not provided by the GEHL Company. For battery specifications see “Electrical-Chassis” chapter. **ALL REPLACEMENT BATTERIES MUST BE PURCHASED LOCALLY.**

Refer to the abbreviations table located on this page for the various fastener descriptions. Standard attaching hardware torque values are also provided on the inside back cover. **If a part requires lubrication or a nonstandard torque value, it will be specified behind the part number description in parenthesis.**

Items shown in the parts list that do not have part numbers are shown for reference purposes only and are NOT available for purchase.

Dimensions are in inches unless otherwise specified.

NOTE: The following abbreviations and symbols may be used herein:

A	Ampere
AR	As Required
ASSY	ASSY
AUX	Auxiliary
CCA	Cold Cranking Amperage
CYL	Cylinder
DH	Dual Hand
DJS	Dual Joystick
FL	Flare
FOPS	Falling Object Protective Structure
GA	Gauge
HEX	Hexagon
H/F	Hand/Foot
HF	High-Flow
HYD	Hydraulic
JIC	Joint Industrial Council
kW	Kilowatt
LBS	Pounds
M	Meter
MM (mm)	Millimeter
NA	Naturally Aspirated
N/A	Not Applicable
NEG	Negative
N•m	Newton meter
NO	Number
NPT	National Pipe Thread
NSS	Not Sold Separately
PN	Part Number
POS	Positive
PSI	Pounds per Square Inch
QTY	Quantity
REF	Reference
REQ'D	Required
ROPS	Roll Over Protective Structure
RPM	Revolutions Per Minute
SAE	Society of Automotive Engineers
SN	Serial Number
SQ	Square
ST	Straight
TB	T-Bar
TB/JS	T-Bar/Joystick
TURBO	Turbocharger
V	Volt

TABLE OF CONTENTS

DESCRIPTION	PAGE
-------------	------

SECTION A: MAIN LOADER COMPONENT

Chassis (includes HVAC, Heater-Only and Power-A-Tach®)	1
Grille and Engine Cover	17
ROPS/FOPS Structure/Interior (includes Non-HVAC, Heater-Only and HVAC)	21
Restraint Bar	29
Seat and Seat Belt Options	31
Lift Arm	39
Attachment Bracket (includes Power-A-Tach®)	41
Wheel Drives	45
Engine	47
Air Cleaner/Exhaust	53
Radiator/Cooler	57
Hydrostatic System with Drive Motors	59
Hydraulics - Chassis (with Auxiliary Hydraulics and Hydraglide™)	67
Hydraulics - Lift Arm	93
Controls - Wheel Drives - Lift/Tilt	97
Controls - Engine	109
Electrical - Chassis (includes Hydraglide™)	111
Electrical - ROPS/FOPS	117
Electrical - Lights	123
Electrical - Engine	125
Electrical - Control	129
Electrical - 14-Pin Auxiliary Connector	131
Four-Point Lift	133
Sound Suppression	135
Brake Release	147
Tires	149
Decals	152

SECTION B: HYDRAULIC COMPONENTS and HEATER/HVAC HOUSINGS

Lift Cylinder	163
Tilt Cylinder	165
Drive Motors with Parking Brake	167
Tandem Pumps	173
Gear Pumps - Single and Double	181
Self-Leveling Valve	185
Solenoid Valves - Lift and Tilt	187
Solenoid Valves - Brake, Joystick Supply and Brake Release	189
Main Control Valves	191
Hydraglide™ Ride Control Manifold Valve	195
Condensor, Heater Housing and HVAC Housing Assembly	197
Foot Valve	199

(continued on next page)

TABLE OF CONTENTS

DESCRIPTION	PAGE
-------------	------

SECTION C: FILTER LISTING, KITS AND ACCESSORIES

Filter Listing, Analysis Kits and Other Available Accessories	200
50850001 Counterweight Kit	201
50352739 Auxiliary Coupler Service Kits	201
811496 Warning Lamp Kit	202
811488 Rearview Mirror Kit	203
811489 AM/FM Radio Kit	204
3-Point Restraint - 2" Seat Belt 810426 and 3" Seat Belt 810427	205
50850344 Backup Alarm Kit for T-Bar Controls	206
805855 Engine Block Heater Kit	207
50850284 Cab Door Kit	208
811487 Side Window Kit	210
Seat Belt Kits - 2" 810424 and 3" 810425	211
Seat Kits - Suspension 810422 and Standard 810423	211
810946 Universal Radio Kit	212
50850342 Pre-Cleaner Kit	213
50850341 Dual Flasher Kit	214
811486 Backup Alarm Kit for Dual Joystick and Hand/Foot	215
50850558 Four-Point Lift Kit	216
50850357 Rear Wiper Kit	217
50850372 Power-A-Tach Kit	218
50450384 Completing Kit for all Power-A-Tach Kits	220
50850396 Cab Heater Kit	221
50850456 Impact-Resistant Front Door Kit	224
50850349 Electric Attachment Control Kit	225
50850457 Single-Point Lift Kit	226
50850556 Pre-Cleaner Kit (Non-DPF Models)	227
50850572 (EU & X-Series) Backup Alarm Kit	228

SECTION D: SCHEMATICS

Electrical Schematic - HVAC	231
Electrical Schematic - Heater/Defroster	232
Electrical Schematic - 14-Pin Connector	233
Hydrostatic/Hydraulic Schematic - Hand/Foot	234
Hydrostatic/Hydraulic Schematic - Dual Joystick	235
Hydrostatic/Hydraulic Schematic - T-Bar	236
Hydrostatic/Hydraulic Schematic - Dual Hand	237
Electrical Schematic - Engine	238
Electrical Schematic - Chassis	240
Electrical Schematic - ROPS	242
Numerical Index	244
O-Ring Table, Coupling & Adapter Torque Table	259
Torque Specifications Table	Inside Back Cover

SECTION A: MAIN LOADER COMPONENTS

Chassis (includes HVAC, Heater-Only and Power-A-Tach®)	1
Grille and Engine Cover	17
ROPS/FOPS Structure/Interior (includes Non-HVAC, Heater-Only and HVAC)	21
Restraint Bar	29
Seat and Seat Belt Options	31
Lift Arm	39
Attachment Bracket (includes Power-A-Tach®)	41
Wheel Drives	45
Engine	47
Air Cleaner/Exhaust	53
Radiator/Cooler	57
Hydrostatic System with Drive Motors	59
Hydraulics - Chassis (with Auxiliary Hydraulics and Hydraglide™)	67
Hydraulics - Lift Arm	93
Controls - Wheel Drives - Lift/Tilt	97
Controls - Engine	109
Electrical - Chassis (includes Hydraglide™)	111
Electrical - ROPS/FOPS	117
Electrical - Lights	123
Electrical - Engine	125
Electrical - Control	129
Electrical - 14-Pin Auxiliary Connector	131
Four-Point Lift	133
Sound Suppression	135
Brake Release	147
Tires	149
Decals	152

Thanks for your reading.

Please click here to download complete manual instantly.

And can also choose other manuals.

Feel free --->write to me with any questions.

Our service email:

manuals007@hotmail.com