

SL5635/6635 Skid Loaders

Form No.
907284

Revision H
03/99



SERVICE PARTS MANUAL

GEHL[®]

Introduction

For your safety and continued proper operation, use only genuine GEHL® service parts. When ordering service parts, specify the correct part number, full description, quantity required, the unit model number and serial number.

The model and serial numbers for this unit are on a Decal located inside the right Chassis Riser, between the Lift Arm and Inner Riser. “Right” and “Left” are determined from a position sitting on the Seat and facing forward.

GEHL ® Company reserves the right to make changes or improvements in the design or construction of any part of the unit without incurring the obligation to install such changes on any previously delivered units.

NOTE: *On original tire replacement, company policy prohibits the sale of replacement tires for all GEHL machinery. Replacement Wheel Sets are available and tire size information is called out with the Wheel Sets to facilitate replacement tire selection. ALL REPLACEMENT TIRES MUST BE PURCHASED LOCALLY.*

NOTE: *Replacement batteries are not provided by the GEHL Company. For battery specifications see pages titled “Electrical Engine Harness/Battery”. ALL REPLACEMENT BATTERIES MUST BE PURCHASED LOCALLY.*

Refer to the abbreviations table located on this page for the various fastener descriptions. Standard attaching hardware torque values are also provided on the inside back cover. **If a part requires lubrication or a non-standard torque value, it will be specified behind the part number description in parenthesis.**

Items shown in the parts list that do not have part numbers are shown for reference purposes only and are NOT available for purchase.

Dimensions are in inches unless otherwise specified.

NOTE: *The following abbreviations may be used herein:*

AMP	Ampere
AR	As Required
ASSY.	Assembly
CCA	Cold Cranking Amperage
CYL	Cylinder
FRT.	Front
FL	Flare
GA	Gauge
HEX	Hexagon
JIC	Joint Industrial Council
kW	Kilowatt
LBS.	Pounds
LT	Left
M	Metric
MM (mm)	Millimeter
NA	Naturally Aspirated
N/A	Not Applicable
NEG	Negative
NILN	Nylon Insert Lock Nut
NO	Number
NPT.	National Pipe Thread
OPER.	Operator
POS.	Positive
PSI	Pounds per Square Inch
QTY	Quantity
REF.	Reference
REQ'D	Required
ROPS.	Roll Over Protective Structure
RPM	Revolutions Per Minute
RT	Right
SAE.	Society of Automotive Engineers
SN	Serial Number
SQ	Square
ST	Straight
TURBO.	Turbocharger
V	Volt

TABLE OF CONTENTS

DESCRIPTION

PAGE

SECTION A: MAIN LOADER COMPONENTS

Chassis	1
Wheel Drives	3
Engine	5
Air Cleaner and Muffler	7
Oil Cooler	9
Hydrostatic System - Single and Two Speed.	11
Hydraulics - Chassis	15
Hydraulics - Lift Arm	19
Auxiliary Hydraulic Controls	23
Controls - Lift and Tilt	27
Controls - Traction	33
Controls - Throttle	39
Lift Arm and Attachment System	43
ROPS and Seat	45
Restraint Bar	49
Sound Suppression	51
Grille and Engine Cover	55
Electrical - Instrument Panel/Harness	57
Electrical - Engine Harness/Battery	59
Electrical - Lights.	61
Decals.	64

SECTION B: HYDRAULIC COMPONENTS

Lift Cylinder	71
Tilt Cylinder	73
Drive Motor and Parking Brake - Single and Two Speed	75
Tandem Pump	79
Gear Pump - Standard	83
Gear Pump - High-Flow	85
Main Control Valve	87
Self-Level Valve	89
Solenoid Valves - Lift and Tilt.	91
Solenoid Valve - Single and Two Speed Brake	93
Manifold - High-Flow	95

SECTION C: BUCKETS, FORKS AND GRAPPLE

All-Tach™ Attachment Buckets	99
Gehl-style Quick-Tach™ Buckets	101
All-Tach™ Pallet Fork	103
Gehl-style Quick-Tach™ Pallet Fork	105

(continued on next page)

TABLE OF CONTENTS

DESCRIPTION

PAGE

SECTION C: BUCKETS, FORKS AND GRAPPLE

All-Tach™ Attachment Utility Grapple.	107
All-Tach™ Attachment Utility Fork	109

SECTION D: ACCESSORIES

Back-Up Alarm Kit 806411	113
Cab - Side Window Kit 806914	114
Cab - Top Window Kit 806843	114
Backhoe Hydraulic Kit 806913	115
Cab - Front Door Kit 807292	116
Cab - Impact Resistant Front Door Kit 807330	117
Cab - Heater/Defroster Kit 806897 (<i>see High-Output below also</i>)	118
Cab - Wiper Kit 806917	119
Upper Auxiliary Tube Kit 807075.	119
Dual Flasher Kit 806920.	120
Horn Kit 806923.	121
Rear Counterweight Kit 806919.	122
Rear View Mirror Kit 806894.	122
Strobe Light Kit 805803.	123
Centrifugal Pre-Cleaner Kit 806281.	123
Engine Auto-Shutdown System Kit 806918	124
Airboss Solid Segmented Tire Repair Parts	125
Loeering Trailblazer Tracks Spacer Kit 134209	126
Lifting Lug Kit 807083	127
Cab - High-Output Cab Heater Kit 807188	128
Double Gas Spring Kit 807376	129
Other Available Accessories	130

Numerical Index	132
O-Ring Table, Coupling & Adapter Torque Table	139
Torque Table.	Inside Back Cover

SECTION A: MAIN LOADER COMPONENTS

Chassis	1
Wheel Drives	3
Engine	5
Air Cleaner and Muffler	7
Oil Cooler	9
Hydrostatic System - Single and Two Speed.	11
Hydraulics - Chassis	15
Hydraulics - Lift Arm	19
Auxiliary Hydraulic Controls	23
Controls - Lift and Tilt	27
Controls - Traction	33
Controls - Throttle	39
Lift Arm and Attachment System	43
ROPS and Seat	45
Restraint Bar	49
Sound Suppression	51
Grille and Engine Cover	55
Electrical - Instrument Panel/Harness	57
Electrical - Engine Harness/Battery	59
Electrical - Lights.	61
Decals.	64

Thanks for your reading.

Please click here to download complete manual instantly.

And can also choose other manuals.

Feel free --->write to me with any questions.

Our service email:

manuals007@hotmail.com